

## LOSA 1711- Aluminum Spindle Carrier Installation Instructions

1. Remove old spindle carrier from vehicle
2. Install new aluminum spindle carrier re-using existing hardware.
3. Adjust the camber turnbuckle until rod end rotates 90 degree's, attach the camber to the spindle with the supplied 5-40 x 3/4 screw.
4. #4 washers are included in the package to allow fine adjustments of front end camber gain.

(\*Note: The stock position of camber link uses no washers)

PN: 800-0325

