

Losi® Temp-Tuner Error Messages and Corrective Measures



'Hi' or 'Lo' is displayed when the temperature being measured is outside of the range of the instrument, 'Hi' when higher than +220°C (428°F) and 'Lo' when lower than -33°C (-91.4°F).



'Er2' is displayed when the Temp-Tuner is exposed to rapid changes in the ambient temperature.



'Er3' is displayed when the ambient temperature of the unit EXCEEDS 0° (32°F) OR +50°C (122°F). In both cases you should allow plenty of time (minimum 30 minutes) for the unit to stabilize to the working/room temperature of 0° to +40°C (32°F to 104°F).



Er5, normally means check sum error of EEPROM.

One/some components was/were shocked by static electricity and dead.

Probably, weather is very dry in winter and causes this problem.



For all other error messages it is necessary to reset the unit. To reset the Temp-Tuner, turn the instrument off, remove the battery and wait for a minimum of one minute, reinsert the battery and turn on. If the error message remains please contact the Service Department for further assistance.